

NIDECKER


MUON - PRIME

TWO-STRAP BINDING INSTRUCTION MANUAL


1 Thank you for purchasing Nidecker bindings. We recommend that your bindings be mounted and maintained by a trained, professional mechanic.

2 All Nidecker bindings can be fully personalized for a superior fit to your boot and riding style. Please go to www.NIDECKER.com for videos, details and tricks & tips for each of our models.

3 In the box: Bindings + Mounting-disks + Mounting-screws



4 Tools needed: PH#3 Screwdriver



PH#3

MOUNTING YOUR BINDINGS TO YOUR BOARD

Montage der Snowboard-Bindungen • Montage de vos fixations sur votre planche • УСТАНОВКА ВАШИХ КРЕПЛЕНИЙ НА ДОСКУ • バインディングをボードに取り付ける

5 Find your preferred stance and angle for your style of riding. If you are not sure, the measurements here are a good starting point.




Riding Styles	Stance	Front	Rear
CARVING <i>Power, Drive & Engagement</i>	NS*	25° - 35°	0° - 15°
ALL-MOUNTAIN <i>Stability, Comfort & Fun</i>	NS + 2cm	15° - 25°	-5° - 5°
FREERIDE <i>Engagement & Stability</i>	NS + 4 cm	20° - 30°	0° - 10°
FREESTYLE <i>Balance, Pop & Fun</i>	NS + 6-10 cm	5° - 15°	0° - -15°

*NS = Natural Stance: Measure from floor to middle of knee


For further assistance, feel free to check out our how-to guide video by scanning this QR code.




6 Check boot in binding position. Centered = toe and heel overhang should be equal.



If needed, adjust hiback-mounting position:




Move hiback back for bigger boots




Move hiback forward for smaller boots




IMPORTANT NOTE: Make sure the forward-lean block can always lean onto the heelcup. The middle mounting-holes are for boot-size adjustment, the outer holes are for hiback-rotation adjustment (see point #12).




7 Open footbed to access mounting-disk: peel up heel corner, fold footbed to front. Push to close.




8 Mount bindings to your snowboard with the supplied disks and hardware.



Our offset multi-disk lets you adjust toe/heel position and stance-width at the same time! Just use the triangle window.



Check board, binding and boot centering.



Point triangle to **toe-edge**: offset binding 3mm more to **toe-edge**.

OR

Point triangle to **heel-edge**: offset binding 3mm more to **heel-edge**.

Point triangle to **nose**: offset binding stance 3mm more to **nose**.

OR

Point triangle to **tail**: offset binding stance 3mm more to **tail**.

9 **IMPORTANT NOTE:** Vibration, temperature changes and board flex all conspire to loosen mounting and other hardware. Please be sure to check all fasteners for tightness before every riding session, and be sure to check if all components are in functional working order.



ADJUSTING YOUR STRAPS

Anpassen der Fußriemen • Ajuster vos sangles de pied • РЕГУЛИРОВКА СТРЕПОВИ • ストラップの調整

10 Adjust the foot-straps so they are centered over the boot with the toe cap-strap placed over the tip/nose of the boot. Pull medial QuickSet buckles to open and adjust, push back to lock.

